

1960-1964 FORD CAR PARTS AND ACCESSORIES

TEXT CATALOG

Autolite 

AUTOLITE-FORD PARTS DIVISION

COPYRIGHT © 1969—FORD MOTOR COMPANY • DEARBORN, MICHIGAN

FORM AF 7681

1969

QUICK REFERENCE INDEX • PAGE

GENERAL INFORMATION
MODEL IDENTIFICATION 11

PAINT 1

SECTIONS 10-24
WHEELS, BRAKES 5

SECTIONS 30-46
FRONT SUSPENSION, STEERING
REAR AXLE, DRIVE SHAFT 49

SECTIONS 50-54
FRAME, EXHAUST SYSTEM, SPRINGS 121

SECTIONS 60-60.9
ENGINE 173

SECTIONS 70-75
MANUAL TRANSMISSION, CLUTCH 259

SECTIONS A70-A74
AUTOMATIC TRANSMISSION 321

SECTIONS 80-86.2
COOLING, GRILLE 387

SECTIONS 90-97
FUEL, CARBURETOR, ACCELERATOR 431

SECTIONS 100-120.4
GENERATOR, ALTERNATOR,
STARTER, DISTRIBUTOR 609

SECTIONS 130-150
LAMPS, WIRING 707

SECTIONS 160-166
FENDER, HOOD 787

SECTIONS 170-190
SPEEDOMETER, WINDSHIELD WIPER,
BUMPER, ACCESSORIES 815

BODY PARTS INDEX 903

BODY SECTIONS 000-100
BODY FRONT, FLOOR 925

BODY SECTIONS 200-300
SIDE, DOOR, PILLAR, QUARTER 975

BODY SECTIONS 400-500
BACK, LUGGAGE COMPARTMENT,
TAILGATE 1083

BODY SECTIONS 600-620
SEATS 1153

SOFT TRIM 1193

MASTER PARTS AND ACCESSORIES CATALOG

FORM AF-7681

1960/64 PASSENGER CAR

AUTOLITE - FORD PARTS DIVISION

DISTRICT OFFICES

Atlanta (East Point, Ga.)	Dallas, Texas	Kansas City, Mo.	Philadelphia (Pennsauken, N.J.)
Boston (Natick, Mass.)	Denver, Colo.	Los Angeles (Pico-Rivera, Calif.)	Pittsburgh, Pa.
Charlotte, N.C.	Des Moines, Iowa	Memphis, Tenn.	Richmond, Va.
Chicago (Melrose Park, Ill.)	Detroit (Livonia, Mich.)	New Orleans (Arabia, La.)	Salt Lake City, Utah
Cincinnati, Ohio	Houston, Texas	New York (Teterboro, N.J.)	San Francisco (Richmond, Calif.)
Cleveland, Ohio	Jacksonville, Fla.	Oklahoma City, Okla.	Seattle, Washington
			Twin City (Minneapolis, Minn.)

INDEX FOR GENERAL INFORMATION SECTION

Abbreviations	XVII, XVIII
Autolite Sales Part Numbers	VI
Basic Body Parts Numbering System	III
Body Type Codes	IV
Catalog Formats	V
Catalog Model Codes	IV
District Offices.....	II
Ford Basic Group Numbers and Related Catalog Section Numbers.....	VIII
FoMoCo Basic Part Numbering.....	IX, X, XI
General Instructions	II
How to Order Parts	VII
Major Group Index	VIII
Model Identification Section.....	V, XIX
Model Year Application	IV
Parts Identification	V
Part Name Index (Body & Chassis).....	VIII
Procedure for using Catalog	VII
Quick Reference Index	I
Section, Group and Basic Numbers	III
Soft Trim	VI
Standard and Utility Hardware.....	V
Symbol (Explanation of ★).....	IV

PATENT or WARRANTY PLATE CODES

Assembly Plant	XIV
Body Color (refer to Paint Section)	
Body Series Codes.....	XIV
Body Type Codes	XV, XVI
Diagrams and Explanation	XII, XIII
District	XVI
Engine Codes & Horsepower Rating	XV
Model Year	XIV
Months of the Year	XVI
Rear Axle Ratio.....	XVII
Transmission Type	XVII
Trim Scheme (refer to Soft Trim Section)	

GENERAL INSTRUCTIONS

This Ford Car Master Parts Catalog contains replacement parts and accessories information for the Ford, Fairlane, Thunderbird and Falcon passenger cars for the model years 1960 through 1964. This "Text" catalog is to be used in conjunction with "Illustration" catalog, Form AF-7682.

The driver's side is the left hand side of the vehicle and should govern in determining such parts as fenders, lamps, etc. as to whether a part is right or left hand.

Refer to the Index above for a listing of the various items appearing in the General Information Section.

SECTION, GROUP and BASIC NUMBERS

For greater convenience this catalog is divided into specific sections; such as brakes, front suspension, engine, transmission, etc. For example, FRONT SUSPENSION appears in section 30, STEERING in section 35, REAR AXLE in section 40, etc. The applicable exploded illustrations are contained in separate sections which are related to the text section numbers. For example STEERING illustrations appear in Illustration Section 35 of the "Illustrations" Catalog, Form AF-7682.

The basic part number groups and the section numbers under which each is listed are shown on page number VII of this general information section.


The basic part number groups shown on page VII have been expanded as shown in the Charts on pages IX, X, XI to provide for additional groups to accommodate new lines. In numerical listings, expanded numbers will be considered to follow the same sequence as the regular basic numbers from which they are expanded and are arranged in Catalogs as follows.

3538
3C538
3634
3A634

Illustrations contain basic group numbers only, therefore, it is necessary to refer to the basic group within this "text" catalog for complete applicable part numbers.

BASIC BODY PARTS NUMBERING SYSTEM

FOLLOWING IS A DIAGRAM OF THE BASIC BODY PARTS NUMBERING SYSTEM



- These five digits comprise the Body Group Numbers as used throughout each body parts section.

A complete group index of body parts has been included at the beginning of the body area. The index is divided into areas of the car in alphabetical sequence; see the first page of the Body Index Section.

EXPLANATION OF SYMBOL ★

- ★ Symbol indicates part is not supplied for service due to the following:
- a. Part is superseded and replaced as indicated in the description column of text.
 - b. Part can be improvised as indicated in the description column of text.
 - c. Due to its function there would be little or no demand.

Note: Always refer to the description column of the text for possible substitution, or for material specifications and dimensions which may be helpful in obtaining the non-serviced part locally.

CATALOG MODEL CODES

(A) Ford (B) Fairlane (62/) (S) Thunderbird (X) Falcon
(A) Fairlane (60/61)

BODY TYPE CODES

Most body parts and some chassis parts are identified by Body Type Codes. A complete listing of body type codes is shown on pages XIV, XV of this General Information Section. Similar body types are identified by the same code number; the body type suffix is used to identify a particular body type. For instance, in 1960/61 the body type code 58 was used as follows:

<u>Body Type Code</u>	<u>Body Type</u>
58A	Fairlane "500" 4 Door Sedan
58E	Fairlane 4 Door Sedan
58F	Custom "300" 4 Door Sedan

Body type codes (less suffix) are shown in the model column of the catalog text or with illustrations titles when all body types of a related group are affected. For example, when body type code 58 is shown, it includes 58A, 58E and 58F.

MODEL YEAR APPLICATION

Model year application is indicated by showing the first year followed by a diagonal line to indicate continued usage in all subsequent years until the insertion of the last year of usage, which will then be inserted after the diagonal line. If no diagonal line is shown the part is applicable only to the year shown.

Example:

60/ indicates part used 1960 through 1964 in this catalog and for subsequent years as indicated in the 1965/ catalog.
61/63 indicates part used 1961 through 1963 model years.
62 indicates part used 1962 model year only.

CATALOG FORMATS

Various formats are used throughout this catalog to coincide with the normal procedure for selecting the affected part numbers. Most areas of the catalog use a format arranged in the order shown below:

Column

- 1 Model year
- 2 Type of vehicle or equipment within a specific model year
- 3 Description, size, etc.
- 4 No. required per vehicle
- 5 Complete part number

Formats peculiar to a particular area of the catalog are generally self explanatory. When necessary, instructions are shown at the beginning of the affected group. For instance, the various charts and parts list method of cataloging in the Carburetor Section are explained on Page 469 of Section 95.

PARTS IDENTIFICATION

To assist in the identification of various parts and major assemblies, identification numbers are shown on the parts themselves or on tags or plates attached to selected major assemblies. Reference to identification numbers is made throughout the catalog, and cross reference charts are provided in some areas to facilitate the selection of the service part number when the identification number is known. It is most important that identification tags and plates be retained with the part or assembly with which they are originally furnished.

MODEL IDENTIFICATION SECTION

Following this General Information Section is a Model Identification Section which includes pictures of the various car lines by model year. This section is provided to assist in the identification of a vehicle when the patent or warranty plate information is not readily available.

STANDARD and UTILITY HARDWARE

Standard and utility hardware, such as bolts, screws, fittings, etc. are listed below the part with which they are used. To facilitate the stocking and handling of standard and utility parts by Ford dealers, locator codes are preassigned by Ford Motor Company. The locator codes are shown in parentheses immediately following or below the standard and utility part numbers. For an example, refer to Body Section 030, Page 941, Group 03086. The part number for a No. 8 x 1" cross recess oval head screw is 52376-S13 and the locator code is U296. In the catalog this item will be shown as 52376-S13 (U296).

AUTOLITE SALES PART NUMBERS - LOCATOR CODES

To facilitate the stocking and handling of those service parts which are assigned both Parts and Accessories Part Numbers and Autolite Sales Part Numbers, the Autolite Sales Part Numbers are shown in parentheses immediately following or below the Parts and Accessories Part Numbers.

For example, refer to Section 96, Page 593, Group 9601. The Parts and Accessories Part Number for a carburetor air cleaner element used on a 1962 Ford with a 6 cylinder 223 C. I. D. engine is C3VY 9601-A and the Autolite Sales part number is FA-4. In the catalog this item will be shown as C3VY 9601-A (FA-4).

SOFT TRIM

Soft Trim parts are arranged in separate sections according to year, that is 1960, 1961 etc. The colored upholstery swatches must be retained from your loose leaf catalog as these have not been included in this publication.

The Soft Trim Sections include only those items which were available for service at the time of printing. Items not shown in the catalog must be improvised or procured locally. Use the following instructions in order to locate the appropriate Soft Trim part numbers.

SOFT TRIM PARTS for ALL MODELS Consists of:

- (1) Parts cataloged by color (e.g. Groups 02344-5, 24346-7, etc.).
- (2) Parts cataloged by trim code (e.g. Groups 23942-3, 62900, etc.).
- (3) Miscellaneous parts (e.g. Groups 47042, 63501, etc.).

PARTS CATALOGED BY COLOR:

- (1) Identify Model, Body Type and Color of desired part.
- (2) Determine Group Number of part.
- (3) Locate appropriate color listed at top of page.
- (4) Match color with model and body type to select desired part number.

FOR EXAMPLE: Should a Black Front Floor Mat (Group 13000-1) be desired for a 1960 Falcon -

- (1) Refer to Group 13000-1
- (2) Read list of colors above title to find "Black"
- (3) Read down to find "X"
- (4) Part number shown is CODZ 6413000 and suffix in "Black" column is EAB.

PARTS CATALOGED BY TRIM CODE:

- (1) Identify Model, Body Type and Trim Code.
- (2) Determine Group Number of part.
- (3) Locate appropriate Trim Code (listing of Trim Codes precedes each body type).
- (4) Match Model and Body with Trim Code to select part number.

FOR EXAMPLE: Should a Front Seat Cushion Cover (Group 62900) be required for a 1964 Ford, Body Type 54E, Trim Code 32 -

- (1) Refer to Group 62900
- (2) Read down to locate A(54E)
- (3) Read Trim Codes (listed numerically) to find Trim Code 32
- (4) Part number shown is C4AZ 6262900 and suffix listed is ADA.

PROCEDURE FOR USING CATALOG

Following is a recommended procedure for using this catalog.

Should an inquiry be received for a rear brake carrier plate for a 1963 Thunderbird, use the following steps.

- A. Refer to the Quick Reference Index on the cover of this catalog. The index shows that parts for Wheels and Brakes are shown in Section 10 through 24 of this catalog. The first section (10) in this group will contain an alphabetical index.
- B. Refer to the Alphabetical Index at the beginning of Section 10 under heading "Brake System"; find name "Plate (rear carrier)". The group number will be shown as 2211-12.
- C. Refer to group 2211-12 and locate the year 1963 in the column head "Year". Refer then to column headed "Model" for "S" which indicates Thunderbird. The part number will be shown as C3SZ 2211-A for right hand and C3SZ 2212-A for left hand.

In the event the proper nomenclature is in doubt, an alternate method of locating basic part number would be as follows.

- A. Refer to the Quick Reference Index on the cover of the Illustration Catalog. The index shows that parts for Wheels and Brakes are shown in Section 10 through 24 of the Illustration Catalog. The first section (10) in this group will contain an index for all illustrations in Sections 10 through 24.
- B. Refer to the Illustration Index at the beginning of Section 10 under heading "Front and Rear Brakes" and find the illustration applicable to rear brakes for 1963 Thunderbird. (Page 49).
- C. Refer to the illustration on page 49 and identify the proper part. It will show a Group number of 2211-12.
- D. Refer to Group 2211-12 and locate the year 1963 in the column headed "Year". Refer then to column headed "Model" for "S" which indicates Thunderbird. The part number will be shown as C3SZ 2211-A for right hand and C3SZ 2212-A for left hand.

HOW TO ORDER PARTS

When ordering parts, always give the complete part number.

In the event the part number is not known, the following information should be included.

- A. Complete description of part.
- B. Model year and body type
- C. Dimension, number of teeth, size, etc.; if possible rough sketch of part.
- D. If applicable to engine, transmission, axle, steering, etc.; specify type; such as 390 cubic inch, Fordomatic, Power Steering, etc.
- E. Advise how shipment is to be made - Freight, Express, Air, Parcel Post.

MAJOR GROUP INDEX (Alphabetically Listed)

Below are various major groups appearing in the Chassis and Body Sections of this catalog. An alphabetical index covering the service details and related parts for each major group of the Chassis parts area of this catalog is listed at the beginning of the section indicated below. A separate Body Index Section is shown at the beginning of the Body parts area of this catalog. In addition, a Quick Reference Index is shown on the cover.

CHASSIS PARTS INDEX							
GROUP	SECTION	GROUP	SECTION	GROUP	SECTION	GROUP	SECTION
Accelerator Linkage	90	Fenders	160	Linkage (steering)	30	Stabilizer	50
Air Conditioner	170	Frame	50	Manifold	90	Steering Gear	30
Alternator	100	Front Suspension	30	Mirrors	170	Steering Linkage	30
Axle (rear)	30	Fuel Pump	90	Paint	Paint	Suspension (front)	30
Battery	100	Fuel System	90	Pump (fuel)	90	Tachometer	170
Brake System	10	Gear Shift	70	Pump (water)	80	Tank (fuel)	90
Bumpers	170	Generator	100	Radiator	80	Tools	170
Carburetor	90	Grille	80	Radio	170	Thermactor	170
Carrier (wheel)	10	Heater	170	Rear Axle	30	Transmission (auto.)	A70
Clutch	70	Hood	160	Regulator (voltage)	100	Transmission (manual)	70
Cooling System	80	Horns	130	Shaft (drive)	30	Voltage Regulator	100
Distributor	100	Ignition System	100	Shift (gear)	70	Water Pump	80
Drive Shaft	30	Instrument Cluster	100	Shock Absorber	170	Wheels	10
Engines	60	Jack	170	Speed Control	90	Windshield Washer	170
Exhaust System	50	Lamps	130	Speedometer	170	Windshield Wiper	170
Fan	80	Linkage (accelerator)	90	Springs	50	Wiring	130

BODY PARTS INDEX							
GROUP	SECTION	GROUP	SECTION	GROUP	SECTION	GROUP	SECTION
Back	*	Door (front)	*	Instrument Panel	*	Seat (auxiliary)	*
Body Assembly	*	Door (rear)	*	Luggage Compartment	*	Seat (front)	*
Body Side	*	Floor	*	Package Tray	*	Seat (rear)	*
Console Panel	*	Front	*	Quarter	*	Top (folding)	*
Center Pillar	*	Glove Compartment	*	Roof	*	Windshield	*

FORD BASIC GROUP NUMBERS and RELATED CATALOG SECTION NUMBERS

A more detailed listing of the basic group numbers, their related expansion numbers and functional areas is shown on the next three pages

CHASSIS PARTS BASIC GROUP NUMBER	CATALOG SECTION NO.	CHASSIS PARTS BASIC GROUP NUMBER	CATALOG SECTION NO.	CHASSIS PARTS BASIC GROUP NUMBER	CATALOG SECTION NO.	BODY PARTS BASIC GROUP NUMBER	BODY SECTION NO.
1000 - 1999	10	3.03 - 1963/	70.4	10000 - 10299	100	00000 - 02999	000
2000 - 2199	20	D/4/S - 1962/	70.5	10300 - 10599	103, 103.1	03000 - 04199	030
2200 - 2299	22	F/4/S - 1964/	70.6		thru 103.5	04200 - 09999	042
2300 - 2399	23	W/4/S - 1960/	70.7	10600 - 10999	106	10000 - 19999	100
2400 - 2999	24	Manual Trans. - linkage, etc.		11000 - 11999	110, 110.1	20000 - 20999	200
3000 - 3499	30	7000 - 7299	71		thru 110.3	21000 - 21999	210
3500 - 3599	35	7300 - 7400	73	12000 - 12999	120	22000 - 22999	220
3600 - 3999	36, 37	7500 - 7999	75	Dist. Parts Lists	120 thru	23000 - 23999	230
4000 - 4599	40	Automatic trans. Parts Lists -			120, 4	24000 - 25999	240
4600 - 4999	46	Ident. & Appl. Chart	A70	13000 - 13399	130	26000 - 26999	260
5000 - 5199	50	F/M/2 - 1960/64	A70.2	13400 - 13699	134	27000 - 27999	270
5200 - 5299	52	C/M - 1960/	A70.3	13700 - 13999	137	28000 - 28999	280
5300 - 5399	53	C4 - 1964/	A70.4	14000 - 14399	140	29000 - 29499	290
5400 - 5999	54	Automatic Trans. - linkage, etc.		14400 - 14499	144	29500 - 29999	295
6000-6898 Engine I.D. Chart	60	7000 - 7199	A71	14500 - 14999	145	30000 - 39999	300
6 cyl. 1.144, 170, 200	60.1	7200 - 7399	A72	15000 - 15999	150	40000 - 41999	400
6 cyl. 223	60.2	7400 - 7999	A74	16000 - 16099	160	42000 - 42999	420
8 Cyl. 221, 260, 289, 289 Spl.	60.3	8000 - 8499	80	16100 - 16599	161	43000 - 43999	430
8 cyl. 292	60.4	8500 - 8599	85	16600 - 16999	166	44000 - 49999	440
8 Cyl. 352, 390 & SPECIALS	60.6	8600 - 8999	86	17000 - 17299	170	50000 - 50999	500
8 cyl. 406, 427	60.7	9000 - 9299	90	17300 - 17399	173	51000 - 51999	510
8 cyl. 430	60.9	9300 - 9399	93	17400 - 17599	175	52000 - 52999	520
Manual trans. Parts	Lists-	9400 - 9499	94	17600 - 17999	176	53000 - 59999	530
Ident. & Appl. Chart	70	9500 - 9599	95	18000 - 18399	180	60000 - 60999	600
2.77 - 1960/	70.1	CARBURETOR PARTS LISTS	95.1 thru 95.22	18400 - 18999	184	61000 - 61999	610, 615, 617
2 15/16 - 1960/62	70.2	CARB. KIT COMPONENTS	95A	19000 - 19999	190	62000 - 69999	620
O/D - 1960/	70.3	9600 - 9699	96	70000 - 79999	A70.1 thru	00000 - 69999	SOFT TRIM - By MODEL YEAR
		9700 - 9999	97		A70.5	(AS APPLICABLE)	

* For complete Body Index refer to Page 903.

FORD MOTOR COMPANY BASIC PART NUMBERING

CHASSIS, ENGINE and ELECTRICAL BASIC NUMBER SERIES

BASIC PART NO. SERIES	BASIC SERIES EXPANSION	PARTS WHICH QUALIFY BY FUNCTIONAL AREA	BASIC PART NO. SERIES	BASIC SERIES EXPANSION	PARTS WHICH QUALIFY BY FUNCTIONAL AREA
1000-1250	1A000-1A250	Wheels, hubs, and drums	13000-13299	13A000-13A299	Headlamps & parking lamps
1251-1349	1A251-1A349	Open numbers	13000-13399	13A300-13A399	Turn signal
1350-1499	1A350-1A499	Spare wheel carrier	13400-13699	13A400-13A699	License, tail, and stop lamps
1500-1724	1A500-1A724	Tires and tubes	13700-13799	13A700-13A799	Courtesy, dome and instrument lamps and switches
1725-1999	1A725-1A999	Open numbers			
2000-2874	2A000-2A874	Brakes	13800-13949	13A800-13A949	Horn
2875-2999	2A875-2A999	Air compressor	13950-13999	13A950-13A999	Open numbers
3000-3499	3A000-3A499	Front axles and front suspensions	14000-14689	14A000-14A689	Wiring and circuit breakers, terminals and connectors, window regulator, fuse panel
3500-3776	3A500-3A776	Steering gear and steering wheel			Seat regulator (electrical)
3777-3999	3A777-3A999	Open numbers	14690-14724	14A690-14A724	Junction boxes and electric conduit
4000-4999	4A000-4A999	Rear axle and driveshaft and coupling shaft	14725-14999	14A725-14A999	Clocks & cigar lighter
		Frame and brackets	15000-15074	15A000-15A074	Lamp assy. - cluster
5000-5149	5A000-5A149	*	15075-15114	15A075-15A114	*
5150-5199	5A150-5A199	Muffler, exhaust pipes, and brackets	15115-15199	15A115-15A199	
5200-5299	5A200-5A299				
5300-5350	5A300-5A350	Front springs	15200-15399	15A200-15A399	Road & spotlamps
5351-5416	5A351-5A416	Sub-frame (for cab mounting)	15400-15489	15A400-15A489	Lamp assy. - marker
5417-5454	5A417-5A454	Open numbers	15490-15579	15A490-15A579	Lamp assy. back up & utility
5455-5481	5A455-5A481	Front springs-clips, studs, and bushings	15580-15599	15A580-15A599	Lamp assy. - Police flasher
			15600-15649	15A600-15A649	*
5482-5499	5A482-5A499	Stabilizer and attaching parts	15650-15655	15A650-15A655	Map lamp
5500-5515	5A500-5A515	Front spring covers	15656-15699	15A656-15A699	Top control
5516-5999	5A516-5A999	Rear springs and attaching parts	15700-15724	15A700-15A724	Engine compartment lamp
6000-6899	6A000-6A899	Engine and mounts	15725-15759	15A725-15A759	Commercial pump motors
6900-6944	6A900-6A944	*			Note: Not used Passenger Car, Truck & Industrial Engines
6945-6999	6A945-6A999	Eng. installation & dress-up kits	15760-15799	15A760-15A799	Open numbers
7000-7999	7A000-7A999	Transmission and clutch	15800-15849	15A800-15A849	Lamp assy. - transmission control selector indicator
8000-8499	8A000-8A499	Radiator and grille parts			Parking brake signal
8500-8599	8A500-8A599	Water pumps	15850-15874	15A850-15A874	Open numbers
8600-8669	8A600-8A669	Fan and brackets	15875-15899	15A875-15A899	
8670-8999	8A670-8A999	Open numbers			
9000-9423	9A000-9A423	Fuel tank, gauges, pumps & lines	15900-15999	15A900-15A999	*
9000-9269	9A000-9A269	Fuel tank, gauges, pumps & lines	16000-16299	16A000-16A299	Front fender, aprons & shields
9424-9499	9A424-9A499	Manifold, clamps, thermostats etc.	16300-16449	16A300-16A449	Rear fenders
9500-9699	9A500-9A699	Carburetors & air cleaners	16450-16549	16A450-16A549	Running boards and brackets
9700-9899	9A700-9A899	Thermostatic choke, acc. spark & throttle control rods	16550-16579	16A550-16A579	Splash shields
			16580-16599	16A580-16A599	Open numbers
9900-9999	9A900-9A999	*	16600-16999	16A600-16A999	Hood, brackets and controls
10000-10399	10A000-10A399	Generators & alternators	17000-17149	17A000-17A149	Tools
10400-10499	10A400-10A499	Open numbers	17150-17249	17A150-17A249	Open numbers
10500-10649	10A500-10A649	Generator regulator	17250-17384	17A250-17A384	Speedometer and tachometer
10650-10837	10A650-10A837	Batteries & ammeters	17385-17399	17A385-17A399	Open numbers
10838-10999	10A838-10A999	Instrument cluster & controls	17400-17674	17A400-17A674	Wipers and washers
11000-11529	11A000-11A529	Starting motor & starter switch	17675-17748	17A675-17A748	Rear view mirrors
11530-11568	11A530-11A568	Open numbers	17749-17999	17A749-17A999	Front and rear bumpers and stone deflectors
11569-11619	11A569-11A619	Ignition switch			
11620-11644	11A620-11A644	Open numbers	18000-18199	18A000-18A199	Shock absorbers
11645-11688	11A645-11A688	Lighting switch	18200-18241	18A200-18A241	*
11689-11999	11A689-11A999	Open numbers	18242-18699	18A242-18A699	Heaters
12000-12427	12A000-12A427	Coil, distributor & spark plugs	18700-18799	18A700-18A799	Air brakes
12428-12449	12A428-12A449	Open numbers	18800-19499	18A800-19A499	Radio
12450-12499	12A450-12A499	Engine governor	19500-19549	19A500-19A549	Miscellaneous Accessories
12500-12999	12A500-12A999	Open numbers	19550-19999	19A550-19A999	Air conditioners

* This series has become inactive and parts qualifying will be identified with part numbers from a more appropriate series.

BODY BASIC NUMBERS and CORRESPONDING FUNCTIONS

BASIC PART NO. SERIES	BASIC SERIES EXPANSION	PARTS WHICH QUALIFY BY FUNCTIONAL AREA	BASIC PART NO. SERIES	BASIC SERIES EXPANSION	PARTS WHICH QUALIFY BY FUNCTIONAL AREA
00000-00099	000A00-000A99	Body assy. & trim sets	25900-25999	259A00-259A99	Open
00100-00399	001A00-003A99	Front end assembly	26000-26199	260A00-261A99	Rear door reinforcement
01400-01499	014A00-014A99	Ventilating ducts & valves	26200-26399	262A00-263A99	Rear door glass frame
01500-01599	015A00-015A99	Brake pedal support	26400-26699	264A00-266A99	Rear door lock & handles
01600-01799	016A00-017A99	Dash assembly	26700-26799	267A00-267A99	Open
01800-01999	018A00-019A99	Ventilating ducts & valves	26800-26899	268A00-268A99	Rear door hinge
02000-02699	020A00-026A99	Cowl & front body pillar	26900-26999	269A00-269A99	Open
02700-02899	027A00-028A99	Open	27000-27299	270A00-272A99	Rear door check & regulator
02900-02999	029A00-029A99	Body front tie bow braces, etc.	27300-27399	273A00-273A99	Rear door regulator vacuum lift
03000-03999	030A00-039A99	Windshield assembly	27400-27699	274A00-276A99	Rear door trim
04000-04249	040A00-042A99	Visor assembly	27700-28099	277A00-280A99	Quarter & quarter panel assy.
04250-04399	042A50-043A99	Front belt rail inst. panel assy.	28100-28399	281A00-283A99	Quarter lock pillar
04400-04599	044A00-045A99	Panel assy. -instr. panel details	28400-28499	284A00-284A99	Open
04600-04799	046A00-047A99	Cigar lighter assy. & instr. cluster	28500-28699	285A00-286A99	Quarter header & frame
			28700-28799	287A00-287A99	Quarter belt rail
04800-04899	048A00-048A99	Ash receptacle assy.	28800-28999	288A00-289A99	Open
04900-05999	049A00-059A99	Open	29000-29199	290A00-291A99	Quarter window garnish mldg.
06000-06199	060A00-061A99	Glove compt. assy.	29200-29599	292A00-295A99	Quarter reinf. braces & brkts.
06200-09999	062A00-099A99	Open	29600-29999	296A00-299A99	Quarter window, glass & channel
10000-10999	100A00-109A99	Floor side & cross members	30000-30199	300A00-301A99	Quarter glass run & regulator
11000-11099	110A00-110A99	Underbody assy.	30200-30299	302A00-302A99	Quarter vent. window
11100-11499	111A00-114A99	Floor pan assy, silencers & pads	30300-30699	303A00-306A99	Qtr. window regulator & frame
11500-11799	115A00-117A99	Floor board assy.	30700-30799	307A00-307A99	Quarter arm rest ash receptacle
11800-11999	118A00-119A99	Open	30800-30999	308A00-309A99	Open
12000-12099	120A00-120A99	Floor board riser	31000-31499	310A00-314A99	Quarter trim assy. & assist loop
12100-12299	121A00-122A99	Floor trans. cover dust sealer	31500-31599	315A00-315A99	Open
12300-12599	123A00-125A99	Open	31600-31899	316A00-318A99	Qtr. arm rest assy.
12600-12699	126A00-126A99	Floor skid strip	31900-31999	319A00-319A99	Quarter panel spare wheel compt.
12700-12999	127A00-129A99	Open	32000-32199	320A00-321A99	Open
13000-13199	130A00-131A99	Floor mat & carpet	32200-32399	322A00-323A99	Side slats-trim sticks-anti-squeaks
13200-13299	132A00-132A99	Floor scuff plate			
13300-13499	133A00-134A99	Open	32400-32499	324A00-324A99	Quarter folding compt. -pkg.
13500-13599	135A00-135A99	Floor tool box	32500-39999	325A00-399A99	Open
13600-13799	136A00-137A99	Open	40000-40199	400A00-401A99	Back door & luggage compartment
14000-14199	140A00-141A99	Member assy. body side frt. & rr.	40200-40399	402A00-403A99	Tail gate & back panel assy.
14200-14299	142A00-142A99	Sill assy. -floor pan cross front	40400-40499	404A00-404A99	Lift gate
14300-19999	143A00-199A99	Open	40500-40599	405A00-405A99	Open
20000-20799	200A00-207A99	Body side and front door	40600-40699	406A00-406A99	Luggage compt. door panel
20800-21099	208A00-210A99	Front door garnish mldg.	40700-40799	407A00-407A99	Tail gate panel assy.
21100-21299	211A00-212A99	Front door reinforcement	40800-40999	408A00-409A99	Back door & tail gate frame assy.
21300-21399	213A00-213A99	Open	41000-41099	410A00-410A99	Back door pillar fillers
21400-22399	214A00-223A99	Front door glass, lock & frame	41100-41199	411A00-411A99	Open
22400-22499	224A00-224A99	Front door handles	41200-41299	412A00-412A99	Deck pillar group
22500-22599	225A00-225A99	Open	41300-41399	413A00-413A99	Luggage compt. & lift gate door header
22600-22699	226A00-226A99	Front door handles-inside	41400-41599	414A00-415A99	Open
22700-22799	227A00-227A99	Open	41600-41699	416A00-416A99	Tail gate framing
22800-22899	228A00-228A99	Front door hinge	41700-41899	417A00-418A99	Back belt rail
22900-22999	229A00-229A99	Front door ventilating window	41900-41999	419A00-419A99	Back door glass & framing
23000-23399	230A00-233A99	Front door dovetail & regulator	42000-42299	420A00-422A99	Back window glass & frame assy.
23100-23499	231A00-234A99	Front door & window regulators	42300-42499	423A00-424A99	Back window garnish moulding
23500-23499	234A00-235A99	Front door check	42500-42599	425A00-425A99	Back door finish strip-mouldings
23600-23699	236A00-236A99	Open	42600-42699	426A00-426A99	Tail gate cross finish strip
23700-24199	237A00-241A99	Front door trim & arm rest	42700-42899	427A00-428A99	Luggage compt. hinge assy. - lamp assy.
24200-24299	242A00-242A99	Hydraulic window operating			
24300-24599	243A00-245A99	Center pillar assy.	42900-42999	429A00-429A99	Back door hinge & reinf. assy.
24600-24999	246A00-249A99	Rear door assy. & panels	43000-43099	430A00-430A99	Tail gate hinge assy.
25000-25099	250A00-250A99	Rear door frame & pillar assy.	43100-43199	431A00-431A99	Back door & tail gate lock
25100-25399	251A00-253A99	Rear door header & bottom	43200-43399	432A00-433A99	Luggage compt. lock assy.
25400-25899	254A00-258A99	Rear door glass & garnish mldg.			

BODY BASIC NUMBERS and CORRESPONDING FUNCTIONS - continued

BASIC PART NO. SERIES	BASIC SERIES EXPANSION	PARTS WHICH QUALIFY BY FUNCTIONAL AREA	BASIC PART NO. SERIES	BASIC SERIES EXPANSION	PARTS WHICH QUALIFY BY FUNCTIONAL AREA
43400-43499	434A00-434A99	Back door handle assembly	55000-55199	550A00-551A99	Top luggage carrier
43500-43699	435A00-436A99	Luggage comp. locking handle	55200-55999	552A00-559A99	Open
43700-43899	437A00-438A99	Back door & lugg. compt. w/strip	60000-60024	600A00-600A24	Front seat complete-less trim
43900-43999	439A00-439A99	Tail gate bumper & dowel	60025-60049	600A25-600A49	Rear seat assy. -opera seat assy.
44000-44099	440A00-440A99	Back window regulator assy.	60050-60099	600A50-600A99	Front & rear seat assy.
44100-44199	441A00-441A99	Back door check assy.	60100-60124	601A00-601A24	Driver's seat adjustment
44200-44299	442A00-442A99	Luggage compt. lid support	60125-60199	601A25-601A99	Rear & deck seat-back assy.
44300-44399	443A00-443A99	Open	60200-60299	602A00-602A99	Driver's seat back assy. comp.
44400-44599	444A00-445A99	Tail gate support	60300-60499	603A00-604A99	Front seat cushion frame assy.
44600-44699	446A00-446A99	Back reinforcement brackets	60500-60799	605A00-607A99	Rear, aux. & opera cushion framing
44700-44799	447A00-447A99	Back door reinf.	60800-61299	608A00-612A99	Front seat cushion & back frame
44800-45099	448A00-450A99	L/compt. opening & tail gate reinf.	61300-61399	613A00-613A99	Rear seat back frame
45100-45199	451A00-451A99	Luggage compt. drain trough	61400-61499	614A00-614A99	Rear seat side pillar-front seat side board
45200-45399	452A00-453A99	Back trim & curtain	61500-61599	615A00-615A99	Rear seat side panel
45400-45599	454A00-455A99	Luggage compt. trim			
45600-45699	456A00-456A99	Luggage tool compartment			
45700-45799	457A00-457A99	Luggage comp. partition board	61600-61699	616A00-616A99	Front seat back panel
45800-45899	458A00-458A99	Luggage compt. shelf board	61700-62099	617A00-620A99	Front seat adjusting
45900-45999	459A00-459A99	Luggage compt. lamp assy.	62100-62499	621A00-624A99	Front & rear seat back reinf.
46000-46099	460A00-460A99	Compartment pkg. compartment	62500-62599	625A00-625A99	Driver & passenger seat suppt. - rear seat legs
46100-46199	461A00-461A99	Tool compartment	62600-62799	626A00-627A99	Front seat floor rest toe guard
46200-46299	462A00-462A99	Deck step	62800-62899	628A00-628A99	Front seat back robe cord
46300-46399	463A00-463A99	Back door trim			front seat back ash receptacle
46400-46499	464A00-464A99	Luggage compartment trim	62900-63199	629A00-631A99	Front seat cushion cover-center seat opera seat cushion
46500-46999	465A00-469A99	Package tray	63100-63199	631A00-631A99	Front, center, opera & rear seat cushion springs
47000-47299	470A00-472A99	Spare wheel compartment	63200-63499	632A00-634A99	Seat cushion pad, facing & end pipe
47300-47999	473A00-479A99	Open	63500-63699	635A00-636A99	Cushion button & welt binding
48000-48099	480A00-480A99	Rear rack assy.			
48100-49999	481A00-499A99	Open			
50000-50299	500A00-502A99	Roof & top assy.			
50300-50799	503A00-507A99	Folding top parts	63700-63799	637A00-637A99	Front seat side carpet
50800-51299	508A00-512A99	Roof reinforcement retainers	63800-63899	638A00-638A99	Rear & deck seat cushion cover
51300-51399	513A00-513A99	Roof rail assembly	64000-64099	640A00-640A99	Driver's seat rear cover
51400-51599	514A00-515A99	Top bow assy. & dome lamp-brackets & attaching parts	64200-64399	642A00-643A99	Partition window operating mech.
51600-51699	516A00-516A99	Roof rib & slats	64400-64599	644A00-645A99	Front seat back cushion cover
51700-51799	517A00-517A99	Roof drip & finish moulding	64600-64699	646A00-646A99	Seat back, pad & division frame
51800-51899	518A00-518A99	Roof partition	64700-64899	647A00-648A00	Front & center seat spring & pad
51900-52299	519A00-522A99	Roof headlining & support	64800-64999	648A00-649A99	Front, center & opera seat pad, cardboard & cover
52300-52499	523A00-524A99	Roof binding & cardboard	65000-65099	650A00-650A99	Front seat back facing
52500-52599	525A00-525A99	Top back curtain	65100-65199	651A00-651A99	Front seat back trim rail
52600-52699	526A00-526A99	Open	65200-65299	652A00-652A99	Front seat back cushion welt & moulding
52700-52999	527A00-529A99	Top deck & slide quarter	65300-65399	653A00-653A99	Front seat back wadding
53000-53099	530A00-530A99	Top stack-toggle	65400-65499	654A00-654A99	Front seat back misc. trim-hassock assy.
53100-53199	531A00-531A99	Top landau-folding pillar			
53200-53399	532A00-533A99	Top back curtain & hyd. mech.	65500-65599	655A00-655A99	Front seat back bellows
53400-53499	534A00-534A99	Top curtain container	65600-65999	656A00-659A99	Open
53500-53699	535A00-536A99	Top side curtain front & rear	66000-66099	660A00-660A99	Pedestal seat
53700-53799	537A00-537A99	Top covers, pads and retainers	66100-66599	661A00-665A99	Open
53800-53899	538A00-538A99	Quarter curtain	66600-66899	666A00-668A99	Rear & deck seat back cover, pad & spring
53900-54299	539A00-542A99	Folding top & back stay pad	66900-67099	669A00-670A99	Rear seat cardboard & facing
54300-54399	543A00-543A99	Roof pads & wadding-silencers	67100-67199	671A00-671A99	Rear seat back arm rest cover
54400-54499	544A00-544A99	Top dust hood & container	67200-67299	672A00-672A99	Rear seat arm rest
54500-54599	545A00-545A99	Open	67300-67599	673A00-675A99	Rear seat silencer & heelboard
54600-54799	54600-547A99	Folding top compt. & w/strip			
54800-54899	548A00-548A99	Top hold down strap			
54900-54999	549A00-549A99	Roof ventilator			

IMPORTANT: AS EACH INDIVIDUAL EXPANSION SERIES BECOMES EXPANDED OF NUMBERS, ANOTHER SERIES WILL BE ESTABLISHED BY USE OF THE NEXT ALPHABETICAL EXPANSION LETTER SUCH AS 'B' thru 'Z'.

TYPICAL PATENT PLATE - 1960/62

The Patent Plate is located on the left front body pillar on Galaxie and Thunderbird models and on the lock face of left front door on Fairlane and Falcon passenger models. The rating plate for Falcon bus models is attached to the left front door hinge pillar.


The following diagram of the Patent Plate specifies, in the Serial Number: the Model Year, Assembly Plant, Series and Body Style, Engine Type and numerical sequence of assembly.

Indicated in the body specifications are the Body Type, Exterior Paint Color, Trim Scheme, Production Date, Transmission Type and Rear Axle Ratio.

IMPORTANT: Always furnish appropriate Patent Plate information and DSO number if applicable when ordering parts not listed in the Catalog. On 1962 models if the unit is built on a DSO, FSO or PAO (special orders) the complete order number will appear in the DSO space.


The Falcon bus models are cataloged with the Econoline Series. Rating plate information concerning Falcon bus models will be found in the General Information section of the Truck Master Parts Catalog Form AF 7636-A.

PATENT PLATE DIAGRAM




Serial Number (0F52W100001)

- "0"---- 1960 Model
- "F"---- Assembled at Dearborn Plant
- "52"---- Galaxie Series--4 Door Sedan
- "W"---- 8 Cyl. OHV Engine--292 C. I. D.--2-Venturi carb.
- "100001"---- First vehicle assembled during Model Year




1960 - 61

P-3154



1962

P-3708



Style and Body Specifications (54A - BM1 - 32 - 17K - 3 - 8)

- "54A"---- Galaxie - 4 Door Sedan
- **"BM1"---- Kingston Blue lower body, Corinthian White upper body- Conventional two-tone
- ***"32"---- First digit "3" represents material - vinyl and body cloth. Second digit "2" represents color - blue
- "17"---- Seventeenth Day of Month
- "K"---- Month of year - October
- "3"---- Fordomatic (2 speed) Transmission
- "8"---- Rear Axle Ratio of 2.91 to 1
- ▲"11"---- District code number

* When vehicle is two-toned the lower body color code will appear first in the Paint Color Code space. Numerals following the Color Code are for Company information.

** When a trim deviation is used and is not serviced a numerical suffix is added to the Trim Code, ie, (32-1, 32-2). If the trim deviation is serviced an alphabetical suffix is added to the Trim Code, ie, (32A, 32B).

▲ Beginning in 1962, District Code Number will appear in D. S. O. space for all units including regular production.

TYPICAL WARRANTY PLATE - 1963/

The Warranty Plate is located on the Lock Face of left Front Door on all Passenger and Falcon Bus Models.

The following diagram of the Warranty Plate specifies, in the Vehicle Data Line: the Body Type, Exterior Paint Color, Trim Scheme, Production Date, District Code and D.S.O. Numbers, Rear Axle Ratio and Transmission Type.


Indicated in the Vehicle Warranty Number Line, formerly "Serial Number", are: the Model Year, Assembly Plant, Series and Body Type, Engine Type and Numerical Sequence of Assembly.

IMPORTANT:

The District Code Number will appear in DSO space for all Units including regular production. Always furnish appropriate Warranty Plate information and DSO Number, if applicable, when ordering parts not listed in the Catalog. If the Unit is built on DSO, FSO or LPO (Special Orders) the complete Order Number will appear in the DSO space in addition to the District Code Number.


The Falcon Bus Models are cataloged with the Econoline Series. Warranty Plate information concerning these vehicles will be found in the General Information Section of the Truck Master Parts Catalog, Form AF 7636-A.

WARRANTY PLATE DIAGRAM




- " 54A" ---- Galaxie - 4 Door Sedan
- " EM" ---- Viking Blue lower body, Corinthian White upper body - Conventional two-tone (When vehicle is two-toned the lower body color code will appear first. Numerals following the color Code are for Company information)
- " 22" ---- First digit " 2" represents material - Gleam broadcloth and Crush Vinyl. Second digit " 2" represents color - medium Blue. (When a trim deviation is used and is not serviced a numerical suffix is added to the Trim Code, ie, (22-1, 22-2). If the trim deviation is is serviced an alphabetical suffix is added to the Trim Code, ie, (22A, 22B).
- " 17K" ---- Seventeenth Day of Month - October
- " 26" ---- Washington District (and DSO number when applicable)
- " 1" ---- Rear Axle Ratio of 3.00 to 1 (Alpha Code for Equa-lock Axles)
- " 3" ---- Fordomatic (2 speed) Transmission

Black Background Plate Identifies a Unit Painted with M30J (Non-Acrylic) Enamel. (Solid Color Unit or the Lower Body Color when Unit is Two-Tone.)



Grey Background Plate Identifies a Unit Painted with M32J (Acrylic) Enamel. (Solid Color Unit or the Lower Body Color when Unit is Two-Tone.)



VEHICLE WARRANTY NUMBER (SAME AS FORMER SERIAL NUMBER) (*3562X100001*)

- " * * " ---- Asterisks precede and follow the complete Warranty Number to prevent unauthorized addition of numbers or symbols.
- " 3" ---- 1963 Model
- " S" ---- Assembled at Pilot Plant
- " 62" ---- (6) Galaxie 500 Series, (2)-4 Door Sedan
- " X" ---- 8 cyl. OHV Engine--352 C.I.D. --2 Venturi carburetor
- " 100001" ---- First Galaxie Series vehicle assembled at Pilot Plant during Model Year

PATENT or WARRANTY PLATE

EXTERIOR PAINT BODY COLOR CODES

(Refer to Paint Section)

TRIM SCHEME CODES

(Refer to Soft Trim Section)

MODEL YEAR CODES

Code 0....1960

Code 1.... 1961

Code 2.... 1962

Code 3 1963

Code 4....1964

ASSEMBLY PLANT CODES

CODE	ASSEMBLY PLANT	CODE	ASSEMBLY PLANT	CODE	ASSEMBLY PLANT	CODE	ASSEMBLY PLANT
A	Atlanta	G	Chicago	M	Memphis	U	Louisville
B	Oakville	H	Lorain	N	Norfolk	W	Wayne
C	Chester	J	Los Angeles	P	Twin Cities	X	St. Thomas
D	Dallas	K	Kansas City	R	San Jose	Y	Wixom
E	Mahwah	L	Long Beach (60/65)	S	Pilot Plant	Z	St. Louis
F	Dearborn			T	Metuchen		

ENGINE ASSEMBLY PLANT CODES

ENGINE CODE	ENGINE PLANT	ENGINE CODE	ENGINE PLANT
C	Cleveland	E	Ensate - Canada

BODY SERIES CODES

CODE	YEAR 19—	DESCRIPTION	CODE	YEAR 19—	DESCRIPTION
(A) FORD 1960/ (Includes 1960/61 FAIRLANE)					
31	60/61	2 Door Sedan	62	62/	4 Door Sedan
32	60/61	4 Door Sedan	63	62/63	2 Door Hardtop
33	60	2 Door Sedan	64	60/61	4 Door Station Wagon (6 Passenger)
41	60/61	2 Door Sedan	64	62/63	4 Door Hardtop
42	60/61	4 Door Sedan	64	64/	4 Door Hardtop (Fastback)
51	60/	2 Door Sedan	65	62/	Convertible
52	60/	4 Door Sedan	66	60/61	4 Door Station Wagon (9 Passenger)
53	60/61	2 Door Hardtop	66	63/	2 Door Hardtop
53	63/	2 Door Sedan	67	61	4 Door Station Wagon (6 Passenger)
54	60/61	4 Door Hardtop	67	62/63	2 Door Hardtop
54	63	4 Door Sedan	68	60/61	4 Door Station Wagon (9 Passenger)
55	60/61	Convertible	68	63/64	2 Door Hardtop (Fastback)
57	61	2 Door Hardtop	69	60/61	2 Door Station Wagon
60	63/	4 Door Hardtop	69	62/	Convertible
61	60/61	2 Door Station Wagon	71	62	4 Door Station Wagon (6 Passenger)
61	62/64	2 Door Sedan	72	62/	4 Door Station Wagon (6 or 10 Passenger)
62	60/61	4 Door Station Wagon	76	62/	4 Door Station Wagon (6 or 10 Passenger)
			78	62/	4 Door Station Wagon (9 or 10 Passenger)
(B) FAIRLANE 1962/					
31	62/	2 Door Sedan	43	63/	2 Door Hardtop
32	62/	4 Door Sedan	47	62/	2 Door Hardtop
41	62/	2 Door Sedan	48	63/	4 Door Station Wagon
42	62/	4 Door Sedan	49	63/	4 Door Station Wagon
(S) THUNDERBIRD 1960/					
71	60/61	2 Door Hardtop	85	62/	Convertible
73	60/61	Convertible	87	62/	2 Door Hardtop
83	62/	2 Door Hardtop	89	62/63	Convertible
(X) FALCON 1960/					
01	63/	2 Door Sedan	16	63/	4 Door Sedan
02	63/	4 Door Sedan	17	61/62	2 Door Sedan
11	60/62	2 Door Sedan	17	63/	2 Door Hardtop
11	64/	2 Door Hardtop	19	63/	2 Door Sedan
12	60/62	4 Door Sedan	21	60/	2 Door Station Wagon
12	64	Convertible	22	60/	4 Door Station Wagon
13	64	2 Door Hardtop	23	63	2 Door Station Wagon
14	64	Convertible	26	62/	4 Door Station Wagon
15	63/	Convertible	27	60/	Ranchero
			29	61/	Sedan Delivery

PATENT or WARRANTY PLATE

ENGINE CODES and HORSEPOWER RATINGS

(Used in conjunction with engine identification tag codes shown in Section 60, pages 176 & 177).

CODE	ENGINE		CARB.	REMARKS	HORSEPOWER					CODE	ENGINE		CARB.	REMARKS	HORSEPOWER						
	CYL.	C.I.D.			1960	1961	1962	1963	1964		CYL.	C.I.D.			1960	1961	1962	1963	1964		
B	6	223	1V	Police					138	138	R	8	427	8V	Special					425	425
B	8	406	4V	Special							S	6	144	1V			85	85	85	85	85
C	8	289	2V						385	385	T	6	200	1V						116	116
E	6	223	1V	Taxi						195	195	U	6	170	1V					101	101
F	8	260	2V			135	135				V	6	223	1V			135	135	135	135	138
G	8	406	6V	Special					164	164	164	W	8	292	2V	Standard	175	175	175		
J	8	430	4V	Auto. Trans.	375				405	405	X	8	352	2V	Special	220	220	220	220		
K	8	289	4V	Special						271	271	X	8	352	4V	Power Option					250
L	8	221	2V						145	145	Y	8	352	4V	Power Option	300					
M	8	390	6V	Special					400	400	Y	8	352	4V	Special	360					
P	8	390	4V	Police					330	330	Z	8	390	4V			300	300	300	300	
Q	8	390	4V	Special					375		Z	8	390	4V	Special		375				
Q	8	427	4V	Special						410	410	Z	8	390	6V	Special	400				

BODY TYPE CODES

CODE	YEAR	DESCRIPTION	CODE	YEAR	DESCRIPTION
(A) FORD 1960/ (Includes 1960/61 FAIRLANE)					
54A	60/61	Galaxie 4 Door Sedan	64F	60	Fairlane 2 Door Sedan
54A	62/	Galaxie "500" 4 Door Sedan	64G	60	Fairlane 2 Door Sedan (Business Coupe)
54B	62/63	Galaxie 4 Door Sedan	64H	60/61	Custom "300" 2 Door Sedan
54B	64/	Custom "500" 4 Door Sedan	65A	61	Galaxie 2 Door Hardtop
54E	63	Custom "300" 4 Door Sedan	65A	62/63	Galaxie "500" 2 Door Hardtop
54E	64/	Custom 4 Door Sedan	65B	62/63	Galaxie "500XL" 2 Door Hardtop
57B	64/	Galaxie "500" 4 Door Hardtop (Fastback)	71A	62/	Country Squire (9 or 10 Passenger)
57C	64	Galaxie "500XL" 4 Door Hardtop	71B	62/	Country Sedan (6 Passenger)
58A	60/61	Fairlane "500" 4 Door Sedan	71C	62/	Country Sedan (9 or 10 Passenger)
58E	60/61	Fairlane 4 Door Sedan	71D	62	4 Door Ranch Wagon (6 Passenger)
58F	60/61	Custom "300" 4 Door Sedan	71E	60/61	Country Sedan (9 Passenger)
59C	60/61	2 Door Ranch Wagon	71E	62/	Country Squire (6 Passenger)
59E	60/61	2 Door Commercial Ranch Wagon (Courier)	71F	60/61	Country Sedan (6 Passenger)
62A	60/61	Galaxie 2 Door Sedan	71G	60/61	Country Squire (6 or 9 Passenger)
62A	62/64	Galaxie "500" 2 Door Sedan	63		
62B	62/63	Galaxie 2 Door Sedan	71H	60/61	4 Door Ranch Wagon (6 Passenger)
62B	64/	Custom "500" 2 Door Sedan	71H	63	Country Squire (9 Passenger)
62E	63	Custom "300" 2 Door Sedan	71J	61	Country Squire (6 Passenger)
62E	64/	Custom 2 Door Sedan	75A	60/61	Galaxie 4 Door Hardtop
63A	60/61	Galaxie 2 Door Hardtop (Starliner)	75A	62/63	Galaxie "500" 4 Door Hardtop
63B	63/	Galaxie "500" 2 Door Hardtop	75C	63	Galaxie "500XL" 4 Door Hardtop
63C	63/64	Galaxie "500 XL" 2 Door Hardtop (Fastback)	76A	62/	Galaxie "500" Convertible
64A	60/61	Fairlane "500" 2 Door Sedan	76B	60/61	Galaxie Convertible
			76B	62/	Galaxie "500XL" Convertible

(B) FAIRLANE 1962/

54A	62/	4 Door Sedan	65B	63/	"500" 2 Door Sport Coupe
54B	62/	"500" 4 Door Sedan	71B	63/	Custom Ranch Wagon
62A	62/	2 Door Sedan	71D	63/	Ranch Wagon
62B	62/	"500" 2 Door Sedan	71E	63/	Squire
62C	62	"500" 2 Door Sport Coupe	71G	63	Squire
65A	63/	"500" 2 Door Hardtop			

(S) THUNDERBIRD 1960/

S(63A)	60/	2 Door Hardtop	S(76A)	60/	Convertible
S(63B)	62/	2 Door Hardtop (Vinyl Roof)	S(76B)	62/63	Convertible (Sports Roadster)

PATENT or WARRANTY PLATE

BODY TYPE CODES - continued

CODE	YEAR 19__	DESCRIPTION	CODE	YEAR 19__	DESCRIPTION
(X) FALCON 1960/					
54A	63/	4 Door Sedan (Bench)	64A	60/62	2 Door Sedan (Bench)
54B	63/	Futura 4 Door Sedan	64C	62	Futura 2 Door Sedan (Bucket)
54D	64	4 Door Sedan (Deluxe)	66A	60/	Ranchero (Bench)
58A	60/62	4 Door Sedan (Bench)	66B	63/	Deluxe Ranchero (Bench)
59A	60/	2 Door Station Wagon	66H	64/	Deluxe Ranchero (Bucket)
59B	63	Deluxe 2 Door Station Wagon	71A	60/	4 Door Station Wagon
62A	63/	2 Door Sedan (Bench)	71B	62	4 Door Squire
62B	63/	Futura 2 Door Sedan (Bench)	71B	63/	Futura 4 Door Station Wagon
62C	62	Futura 2 Door Sedan (With Thunderbird Roof)	71C	63/	4 Door Squire
62C	63/	2 Door Sedan (Bucket)	71D	63	4 Door Super Deluxe Squire
62D	64/	2 Door Sedan (Deluxe-Bench)	76A	63	Convertible (Bench)
63B	63/	Futura 2 Door Hardtop (Bench)	76A	64/	Convertible (6 cyl. -Bench)
63C	63	Futura 2 Door Hardtop (Bucket)	76B	63	Convertible (Bucket)
63C	64/	2 Door Hardtop (6 cyl. -Bucket)	76B	64/	Convertible (6 cyl. -Bucket)
63D	64/	2 Door Hardtop (8 cyl. -Bucket)	76D	64	Futura Convertible (8 cyl. -Bucket)
63E	64	2 Door Hardtop (8 cyl. -Bench)	76E	64	Futura Convertible (8 cyl. -Bench)
63H	64	Futura 2 Door Hardtop (Bucket)	78A	61/	Sedan Delivery
			78B	63/	Deluxe Sedan Delivery

BODY COLOR CODE
(Refer to Paint Section)

TRIM SCHEME CODE
(Refer to Soft Trim Section)

MONTHS OF THE YEAR CODES

CODE	MONTH - FIRST YEAR	CODE	MONTH - FIRST YEAR	CODE	MONTH - SECOND YEAR	CODE	MONTH - SECOND YEAR
A	January	G	July	N	January	U	July
B	February	H	August	P	February	V	August
C	March	J	September	Q	March	W	September
D	April	K	October	R	April	X	October
E	May	L	November	S	May	Y	November
F	June	M	December	T	June	Z	December

DISTRICT CODES

CODE	DISTRICT	CODE	DISTRICT	CODE	DISTRICT	CODE	DISTRICT
11	Boston	34	Indianapolis	53	Kansas City	75	Phoenix
13	New York	35	Lansing	54	Omaha	83	Government
15	Newark	37	Buffalo	55	St. Louis	84	Home Office Reserve
16	Philadelphia	38	Pittsburgh	56	Davenport	85	American Red Cross
17	Washington	41	Chicago	61	Dallas	89	Transportation Services
21	Atlanta	42	Fargo	62	Houston	90	Thru Export
22	Charlotte	43	Milwaukee	63	Memphis	99	
24	Jacksonville	44	Twin Cities	64	New Orleans	FORD OF CANADA	
25	Richmond	45	Davenport	65	Oklahoma City	B1	Central
27	Cincinnati	46	Indianapolis	71	Los Angeles	B2	Eastern
28	Louisville	47	Cincinnati	72	San Jose	B3	Atlantic
32	Cleveland	51	Denver	73	Salt Lake City	B4	Midwestern
33	Detroit	52	Des Moines	74	Seattle	B6	Western
						B7	Pacific

PATENT or WARRANTY PLATE

REAR AXLE CODES

WITH LOCKING DIFFERENTIAL			WITH LOCKING DIFFERENTIAL		
CODE	YEAR	RATIO	CODE	YEAR	RATIO
A	60/61	3.56	F	61	3.00
	62/	3.00		62	3.56
				64/	2.80
B	60/61	3.89	G	62/	3.80
	62/64	3.10			
C	60/61	3.10	H	61	2.91
	62/	3.20		62/	3.89
D	62/	3.25	I	63/ (Falcon)	4.00
E	62/	3.50		63/ (Ford, Fairlane)	4.11

WITH NON-LOCKING DIFFERENTIAL			WITH NON-LOCKING DIFFERENTIAL		
CODE	YEAR	RATIO	CODE	YEAR	RATIO
1	60/61	3.56	6	60	3.22
	62/	3.00		61	3.00
2	60/61	3.89		62	3.56
	62/64	3.10		64/	2.80
3	60/61	3.10	7	62/	3.80
	62/	3.20			
4	60	3.78	8	60/61	2.91
	61	4.00		62/	3.89
	62/	3.25	9	60	3.70
5	61	3.20		62/ (Falcon)	4.00
	62/	3.50		62/ (Ford, Fairlane)	4.11
			J	60/61	3.50

TRANSMISSION CODES

CODE	YEAR	TYPE	CODE	YEAR	TYPE
1	60/	3 Speed Manual Shift	5	60/	4 Speed Manual Shift
2	60/	Overdrive	6	64/	C4 Automatic (XP)
3	60/64	Fordomatic (2 speed)	C	60	Fordomatic (3 speed)
4	60/	Cruise-O-Matic			

ABBREVIATIONS

2/b or 2/v.....2 barrel	abs.....absorber	blk.....block
3/T or 3/S/T.....3 speed trans.	accel.....accelerator	brg.....bearing
3 or 4/S/T.....3 or 4 speed trans.	adj.....adjustment	brkr.....breaker
4/b or 4/v.....4 barrel	alt.....alternator	brkt.....bracket
4/T or 4/S/T.....4 speed trans.	altnr.....alternating	bus.....business
6/b or 6/V.....6 barrel	alum.....aluminum	
8/b or 8/V.....8 barrel		
A/C.....air conditioner	amp.....ampere	C/CW.....counter clockwise
AR.....As Required	approx.....approximately	C. I. D.....cubic inch displacement
A/S.....air suspension	assy.....assembly	C/L.....Customline
A/T orautomatic transmission	attach.....attached	C/M.....cruise-o-matic
auto. trans.		C. P. or cp.....candle power
		C/W.....clockwise
		C4.....Type of auto. trans.

ABBREVIATIONS

carb..... carburetor
Chg/L..... Change level
clstr..... cluster
c/member..... crossmember
col..... column

com..... compressor
compt..... compartment
con..... control
cond..... conditioning
conn..... connecting

c/pin..... cotter pin
c/shaft..... crankshaft
ctr..... center
cvr. or cov. cover
cyl..... cylinder

D/4/S..... Dagenham 4 speed
def..... defroster
defl..... deflector
dla. or diam..... diameter
diff..... differential
disp..... displacement
dist..... distributor

E/H/D..... Extra Heavy Duty
elec..... electric
em/re..... emission reduction
eng..... engine
equal..... equalizer
exh..... exhaust
ext..... external

F/L..... Fairlane
F/M..... Fordomatic
F/M/2..... Fordomatic 2 speed

F-1..... Ford 1 barrel carb.
F-2..... Ford 2 barrel carb.
F-4..... Ford 4 barrel carb.
F/4/S..... Ford 4 speed

fdr..... fender
fill..... fillister
flex..... flexible
flr..... floor
frt..... front
ft..... foot
f/wheel..... flywheel

gen..... generator
gov..... governor
gr..... gear

H-1..... Holley 1 barrel carb.
H-2..... Holley 2 barrel carb.
H-4..... Holley 4 barrel carb.

H/D..... heavy duty
HP..... horsepower
hd..... head
hex..... hexagon
hsg..... housing
htr..... heater
hyd..... hydraulic

I. D..... inside diameter
ident..... identification
ign..... ignition
Imco..... Improved Combustion
Emission Control System
indic..... indicator
instru..... instrument
int..... internal
inter..... intermediate
I/P..... integral power steering

L. H..... left hand
lb..... pound
lt. /frame..... light weight frame
lub..... lubricator
l/washer or l/w..... lockwasher
lwr..... lower

M/S..... manual steering
M/L..... Mainline
man..... manifold
med..... medium
mldg..... moulding
M/T..... manual transmission
mtd..... mounted
mtg..... mounting
mtr..... motor

NPG..... New Process Gear trans.
No..... number

O. D..... outside diameter
O/D or o/drive..... overdrive
O. H. V..... over head valve
O/S..... oversize
o/all..... overall
oz..... ounce

P/A..... power assist steering
P/C..... Police Car
P. F..... premium fuel
P/I..... Police Interceptor
P/L..... Parklane
P/S..... power steering

pass..... passenger
pcs..... pieces
press..... pressure
pt..... pint

qtr..... quarter
qty..... quantity

R/A..... rocker arm
R/B..... replaced by
R/D..... regular duty
R. F..... regular fuel
R/G..... ring gear
R. H..... right hand
R. P. M. or RPM..... revolutions per minute

rad..... radiator
rd..... round
reg..... regulator
reinf..... reinforcement
repl..... replaced
ret..... retainer
rr..... rear

S/D..... Sedan Delivery
S/E..... Special Economy carb.
S/L..... Sunliner
S/T..... standard transmission
S/W..... Station Wagon

s/member..... side member
s/ring..... snap ring
speedo..... speedometer
spkrs..... speakers
sprg..... spring
std..... standard
strg..... steering
suppt..... support
susp..... suspension

T/E..... Thermactor Emission
Control System
T. V..... throttle valve

tach..... tachometer
temp..... temperature
thd..... thread
trans..... transmission
Trans/ign. or Trans. ign.....
Transistorized Ignition


U/S..... undersize
u/joint or u/jt..... universal joint

vac..... vacuum
vent..... ventilation

W/4/S..... Warner 4 speed
w/..... with
w/o..... without
w/shield or w/s..... windshield
w/strip..... weather strip
warn..... warning
wt..... weight


X/C or x/c..... extra cooling

1960




P-3565

FORD PASSENGER



P-3569


FALCON



P-3567


THUNDERBIRD

1961




P-3566

FORD PASSENGER




P-3570

FALCON




P-3568

THUNDERBIRD



P-3730



GALAXIE



P-3775


FAIRLANE

FORD PASSENGER



P-3789


PASSENGER



P-3741

CLUB WAGON & STATION BUS


FALCON



P-3788


THUNDERBIRD

1963



GALAXIE


P-4014



FAIRLANE

P-4015

FORD PASSENGER




P-4016



P-3741

CLUB WAGON & STATION BUS


FALCON



P-4017


THUNDERBIRD

1964



P-4261


GALAXIE



P-4262

FAIRLANE

FORD PASSENGER



P-4263


PASSENGER



P-3741

CLUB WAGON & STATION BUS

FALCON



P-4260

THUNDERBIRD